

Note!

For Panigale 899: Shorten the shock absorber 5 mm by turning the end eye 5 turns in, before mounting the shock.

For Panigale 959: Shorten the shock absorber 3 mm by turning the end eye 3 turns in, before mounting the shock.

For Streetfighter V2: Reduce the spring preload 3 mm by turning the spring preload adjustment nut 2 turns out.

Kit Contents		
Description	**Part No**	**Pcs**
Shock absorber	DU 1518	1
C-spanner	00710-05	2
Sticker Memo notes	01180-01	1
Sticker set Öhlins		1
Owner's manual	07242-08	1

Note!

Please note that there can be small differences between your product and the images in these instructions.

Note!

Please note that during storage and transport, especially at high ambient temperature, some of the oil and grease used for assembly may leak and stain the packaging. This will not cause damage to the product, wipe off the excessive oil or grease with a cloth.

Note!

Before you install this product, check the kit contents. If anything is missing, please contact an Öhlins dealer.

⚠ Warning!

Before you install this product, read the Öhlins Owner's manual. This product is an important part of the vehicle and the vehicle stability.

Shock absorber for

DUCATI PANIGALE V2

Mounting Instructions

ÖHLINS

MOUNTING INSTRUCTIONS

⚠ Warning!

We strongly recommend to let an Öhlins dealer install this product.

⚠ Warning!

If you work with a lifted vehicle, make sure that it is safely supported to prevent it from tipping over.

👁 Note!

When you work with this product, see the vehicle service manual for vehicle specific procedures and important data.

👁 Note!

Before you install this product clean the vehicle.

1

Put the motorcycle on a work stand so that the rear wheel barely touches the ground.

2

Remove the original shock absorber.

3

Install the Öhlins shock absorber in the same position as the original shock absorber.

👁 Note!


Lower the vehicle so that the suspension is slightly compressed before you tighten the screws.

4

Remove the plastic spring cover from the original shock absorber and install it on the Öhlins shock absorber.

✋ Caution!

Make sure that you tighten all screws to the correct torque and that nothing fouls or restricts movement of the shock absorber/front fork/steering damper when the suspension is fully compressed or extended.




MOUNTING INSTRUCTIONS

This page intentionally left blank

ADJUSTMENTS

⚠ Warning!

Before you ride/drive, always make sure that the setup is according to the recommended setup data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.



SETUP DATA

Length	304 +2/-4	mm
Stroke	54	mm
Rebound	14	clicks
Compression	10	clicks
Spring preload	8	mm
Spring	01093-64	
Spring rate	160	N/mm
Free spring length	150	mm

Recommended sag and ride height, Panigale		
R1-R3	38	mm
F1-F3	44	mm

Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

Part no. MI_DU1518_0
Issued 2026-09-22

© Öhlins Group AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Group AB is prohibited.

Öhlins Group AB
Box 722
S-194 27 Upplands Väsby, Sweden
Phone +46 8 590 025 00
fax +46 8 590 025 80